

The GOODALL® Food & Beverage Hoses family: Cleaning and Disinfection Instruction Guide



Milk and Fatty Foods



Beer, Wine, and Spirits

NUTRALON hose line

Cleaning Instruction Guide

Medium	Concentration	Temperature	
Hot Water		95°C	203°F
Steam		130°C	266°F
Nitric Acid (HNO ₃)	2.0%	20°C	68°F
Caustic Soda (NaOH)	2.0%	85°C	185°F
Peracetic Acid (CH ₃ CO ₃ H)	1.5%	20°C	68°F
Phosphoric Acid (H ₃ PO ₄)	2.0%	65°C	149°F

DelIDRINK hose line

Cleaning Instruction Guide

Medium	Concentration	Temperature	
Hot Water		95°C	203°F
Steam (30 minutes)		130°C	266°F
Nitric Acid (HNO ₃)	2%	25°C	77°F
Caustic Soda (NaOH)	3%	85°C	185°F
Peracetic Acid (CH ₃ CO ₃ H)	1,5%	25°C	77°F
Phosphoric Acid (H ₃ PO ₄)	2%	25°C	77°F
Chloridric Acid	200 ppm	80°C	176°F
Sodium Hypochlorite	200 ppm	80°C	176°F